

reset the start code by manual unlock.

7. Low-battery warning

The battery icon in the upper left will keep flashing when the battery is running low (Fig. 9). If the warning appears, please apply for a new Token from ICBC (Asia) Branch within one month.



Fig. 9

Personal online banking

1. Example of Fund Transfer via personal online banking

- Visit the ICBC (Asia) website, then log on personal internet banking.
- Click on Fund Transfer and fill in the transaction detail. After pressing "Proceed", it will automatically enter the screen of dynamic code input.
- Please turn on the Password Token, and input the last six digits of the payee's account number and transfer amount. Then Press the "OK" button to acquire 6-digit password, and input the password to the dynamic code box in Fig. 10. After that, complete other inputs in the screen and press confirm.
- When the dynamic code passes verification, the online transfer transaction will be completed.




Fig.10

2. Calibrate password token of ICBC (Asia)

- Deviation of internal clock of the password token may result in verification error for dynamic code. If the dynamic code verification goes wrong for twice in a row, please calibrate the password token of ICBC (Asia).
- Click "security center"->"calibrate the password token of ICBC (Asia)", as shown in Fig. 11.



Fig.11

- Please turn on the Password Token, and press the "OK" key directly to obtain the first dynamic Password Token. Then input the password into the code box in the first row.

5

in Fig. 11 and wait for the Password Token to display the next-minute dynamic code. After that, input the next-minute dynamic code to the second row in Fig. 11. Lastly, input the verification code and click "Confirm".

- After two consecutive different dynamic codes pass verification, the timing sync for the code is completed.

Security Tips

1. Keep the password token and set up password token appropriately

The password token of ICBC(Asia) is a dedicated device to verify client identity by generating a dynamic code in transactions. The password token is only for your own use. Please store the Password Token and code appropriately. Once the Password Token is acquired by others, your account security may be undermined. Therefore, please enhance your security awareness and form a good transaction habit to prevent illegal invasions.

- Please store the Password Token appropriately. Once it is lost, please contact ICBC(Asia) asap for loss report.
- Select a start code that is difficult to figure out. Do not use your birthday, card number or serial number of the Password Token. You are suggested to modify the start code to reduce the risk of code leak.
- Do not tell your start code to others in any circumstance.

6

Do not trust any behavior asking for your code by email, telephone or text message. If you have any inquiry please call our customer service hotline (852)218 95588

2. Safe use of Password Token

Please note the following when using the Password Token:

- The transaction information you have inputted in your Password Token represents the real transaction intent of you, so please verify the information before you confirm the transaction.
- Please ensure the transaction information you have inputted in your Password Token is consistent with the information prompted by the system, otherwise the verification will fail.

3. Visit out correct website and call our hotline

When you visit the ICBC(Asia) website, please input the website directly. Do not visit our website through other address, number or link. ICBC(Asia) will never request you to change your password or conduct identity verification through any so-called designated website by email, text message or telephone.

- Website: <http://www.icbcasia.com>
- Mobile Phone Banking: m.icbcasia.com
- Customer Hotline: 218 95588

7

ICBC 工银亚洲

金融@家

Password Token

The product comes with the instruction manual

Instruction of ICBC (Asia)Token



ICBC (Asia)Token

1. Activate

- A new Password Token must be activated before using.
- You will automatically enter the activation process after turning on the Password Token. You can then wait for inputting the activation code. Please follow the prompt in Fig. 1 and input 12-digit activation code to complete activation.
- You must input the activation code correctly, which is printed on the bank receipt. Otherwise it will result in activation failure.
- If the activation fails, press any key to return and reactivate.



Fig. 1

1

2. Set start code

- After activation, the new Password Token will automatically enter the status of setting the start code.
- Please input the start code (6 digits) twice as per prompt in Fig.2 and Fig. 3, in order to complete setting the start code.



Fig. 2



Fig. 3

- The start code that you entered twice must be identical, otherwise it will result in failure. If you have entered the start code incorrectly, press any key to return, and restart the process again.

3. Acquire dynamic code

- Press and hold "OK" to start, then input the start code as prompted (in Fig. 4).
- Then you can enter the code that shown in the transaction into Fig. 5.
- If the start code is wrong, the screen will display the times of consecutive failures (Fig. 6). Press any key to return, and re-enter the start code. If the consecutive failures reach the system controlled times(6 times), the Password Token will be locked. Refer to "6. Unlock" for details of unlock.

2



Fig. 4



Fig. 5



Fig. 6

- Please input the transaction code that shown in the screen. After that, press the "OK" key. If the Password Token does not require inputting the transaction code, press the "OK" key directly. If the input exceeds 12 digits, you can press "←" and "→" to scroll between the input. The little triangle on the upper left and right side of the screen means there is number that is not indicated in the direction. You can use "Del" key to delete the last digit and hold "Del" key to delete all input.
- Display dynamic code: After you have completed inputting the information, the dynamic code will be displayed automatically, as shown in Fig. 7.




Fig. 7

- If you need to acquire the dynamic code again, please press any numeric key and it will direct you to the screen of requiring the transaction code.

4. Modify the start code

In the status of display of dynamic code, press and hold the "OK" key to enter the status of modifying the start code.

3

The operation process is the same as start code initialization.

5. Turn off

- The Password Token will be turned off automatically when there is no action for a long time.
- Press "OK" key to turn it off at any status while it is on.

6. Unlock

If the consecutive wrong input of start code reaches the limit set by the system(6 times), the Password Token will then enter the lockup status, and will display the unlock challenge code automatically, as shown in Fig. 8.




Fig. 8

Automatic unlock

If the pre-set automatic unlock time expires, the Password Token will be automatically unlocked in 24 hours, and the start code remains unchanged. If the automatic unlocks accumulate into 6 times, the Password Token's automatic unlock function will be disabled.

Manual unlock

You can bring your own valid identity card and Password Token to any of our ICBC (Asia) Branches for manual unlock. If you have forgotten the start code, our staff can

4

Product Guarantee Card

Product name: ICBC (Asia) Token
Serial number:

Product Conformance Certificate

The product has passed quality inspection and agrees with ICBC (Asia) Vendor's standards and specifications.

合格证

Product Guarantee Card

- Instructions for product guarantee:
If the product cannot be used due to inherent quality issues in normal use, ICBC (Asia) provides the following guarantee policy
- Check the product back for the guarantee period. If the product cannot be used due to quality problem, you can apply a new one for free during the guarantee period.
 - The following cases are excluded from the free guarantee service (1). The user uses it inappropriately or fails to follow the product use manual.
 - The user had the product repaired by any other company except ICBC (Asia), or replaces, dismantles or modify the product serial number at its own discretion.
 - Human-intervened failure or damage arising from installation or movement.
 - Failure or damage due to force majeure.

Please note that ICBC (Asia)Token is produced by respective vendor. ICBC (Asia) accepts no liability for the quality of token (unless otherwise agreed).